


# NORRSKEN

## DESIGN

Carl Öjerstam

## SAFETY

Minimum safety distance to illuminated object: 0,3 metres.




### NORRSKEN – lighting solutions that leave room for creativity

NORRSKEN wire system makes it easy to furnish with light and highlight your favourite interior design features.

The basic package includes wires, holders, clips and fittings. Stretch the wire between two walls or from floor to ceiling. Then choose the spotlights you need and place them wherever you wish on the wire. STRATOSFÄR spotlight produces a narrow beam of concentrated light that is ideal for highlighting works of art or other interior design features. DYGN spotlight casts a pool of light over a wider area at the same time as it gives you a certain amount of general lighting in the room as a whole. DECENNIUM is a pendant spotlight that spreads light downwards over surfaces such as a bar top, worktop or dining table.

# HOW TO BUILD



**Think first about** what you want to illuminate – pictures, glass, ceramics, plants, etc. Then choose and combine the spotlights you need. STRATOSFÄR produces a narrow beam of concentrated light for spotlighting individual objects or features. DYGN spotlight casts a pool of light over a wider area at the same time as it gives a certain amount of general lighting in the room as a whole. DECENNIUM is a pendant spotlight that spreads light downwards over surfaces such as a bar top, worktop or dining table. The transformer is designed to work with at least four and up to ten spotlights.


**Install the components** of the basic package. The system must be permanently hard-wired and properly secured to the ceiling or wall. Follow the assembly instructions carefully. Switch

off the power at the mains before you install the system. If you encounter any problems, contact a qualified electrician.


**Use at least two wire holders** for lengths over six metres. To turn a corner with the wires your ceiling must be made of solid, durable material; not plaster or similar soft material. Never turn the wires through angles greater than 60° at a time. Instead, use four wire holders and make the turn in two stages.

**Place spotlights** where you need them on the wires. Always leave at least 30 cm between the spotlight and the object it is illuminating.

## BASIC PACKAGE



1 transformer,  
Min 80W - Max 200W




1 wire with connector to  
transformer, 9 metres long.



2 turnbuckle screws



4 wire holders



1 wire for connection to  
transformer, 0,6 metres long.



4 wire fittings



4 wire locks



8 wire protectors




2 wire clips

Price for the basic package  
00120432 **SR 385**

## SPOTLIGHTS



STRATOSFÄR Design: Richard Clack.  
20120450 **SR 55**



DYGN Design: IKEA of Sweden.  
90120456 **SR 65**



DECENNIUM Design: M Lundström/F Magnusson  
60120453 **SR 85**



All the products (shown here) may not be available at the store. Please contact the staff for more information. For more detailed product information, see the pricetag and the Internet. All units require assembly.